


OWNER'S MANUAL: Vertical Rack Rail (2U – 20U)



THIS MANUAL APPLIES TO THE FOLLOWING SKUs:					
00301237	00301238	00301239	00301240	00301241	00301242
00301243	00301244	00301245	00301246	00301247	00301248

Keep this information for further reference.

Thank you for purchasing a NavePoint product. If you have any questions regarding the installation or use of your product, please call us at 888.505.1363.

Please examine the product for any damaged parts. If any part is damaged or missing, contact NavePoint for assistance. Do not attempt to install or use product if it has been damaged. This product contains small items that could be a choking hazard – keep these items away from children.


During installation, lay product contents on cardboard or other protective surface to avoid any damage.


Do not use with equipment that is heavier than the indicated weight capacity for this product. This product is designed to be installed indoors on wood stud walls, solid concrete walls or brick walls. Make sure that the supporting surface will safely support the weight of the equipment and all attached hardware and components. It is recommended that installation be performed by a qualified installer. NavePoint Assumes no responsibility for the use, application, or reliability of the software and/or hardware that you install into the product. Always install the heaviest equipment in the bottom of the product. NavePoint cannot be held responsible for damage to equipment or personal injury resulting from improper use or installation of product.

Maintenance: Check that the product is secure and safe to use at regular intervals (at least every three months).

Limitations of Liability: In no event will NavePoint, LLC. be liable for any damages, whether direct or indirect, special, punitive, incidental or consequential damages (including, but not limited to, lost profits or revenue, loss of use, lost business opportunities or loss of goodwill) or for the costs of procuring substitute products, arising out of or in connection with the use of the product, whether such liability arises from any claim based upon contract, warranty, tort (including negligence), product liability or otherwise, whether or not seller has been advised of the possibility of such loss or damage. In no event will seller's total cumulative liability, from all causes of action and all theories of liability, exceed the total amounts actually paid to seller by customer for the item that gives rise to any liability hereunder.

1. Feature Identification



Equipment Mounting Hardware (Rack Units * Number of Screws)			
 12 - 24 Mounting Screws	• 2U x8	8U x32	14U x56
	• 3U x12	9U x36	16U x64
	• 4U x16	10U x40	18U x72
	• 6U x24	12U x48	20U x80

2. Installation

